


Manual de instrucciones

Movimiento 2353-3H

BATERÍA: 377 / SR626SW

A) ESFERA



B) AJUSTE DE LA HORA

1. Tire de la corona hasta la 2ª posición.
2. Gire la corona para ajustar las manecillas de hora y minutos.
3. Cuando la corona se empuja de nuevo a la posición normal, la manecilla de los segundos comienza a moverse.

C) AJUSTE DE LA FECHA

1. Tire de la corona hasta la 1ª posición.
2. Gire la corona hacia la izquierda para ajustar la fecha.

Importante: Si se ajusta la fecha entre las horas de las 9:00 PM y 1:00 AM, la fecha puede que no cambie al día siguiente.


3. Después de la fecha se ha fijado, colocar la corona a la posición normal.

Manual de instrucciones

Movement 2353-3H

BATTERY: 377 / SR626SW

A) DISPLAY



B) SETTING THE TIME.

1. Pull the crown out to the 2nd position.
2. Turn the crown to set hour and minute hands.
3. When the crown is pushed back to the normal position, second hand begins to run.

C) SETTING THE DATE

1. Pull the crown out to the 1st position.
2. Turn the crown counter-clockwise to set the date.

Important: If the date is set between the hours of around 9:00 PM y 1:00 AM, the date may not change the following day.

3. After the date has been set, push the crown back to the normal position.